

AIR RAID[®]

INTAKE SYSTEMS

#301-139 INSTALLATION INSTRUCTIONS

94-02 Dodge Cummins Turbo Diesel Quick Fit

Thank you for purchasing the Airaid Intake System. Please read the instruction manual carefully before proceeding with the installation. Contact Airaid @ (800) 498-6951 8:00 AM - 5:00 PM MST weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid Intake System was carefully inspected and packaged. Check that no parts are missing, or were damaged during shipping. If any parts are missing, contact Airaid. The air filter element is protected from direct exposure to water and debris; care should be taken not to drive through deep water. WATER INGESTION IS THE DRIVERS RESPONSIBILITY!

Thank you for selecting Airaid.



Packing List:

721-128	Airaid Premium Filter	1
KIT139FPC	Front Panel	1
KIT139MAFC	MAF Panel	1
KITWSTRIP02	Weather Strip 35 1/2"	1
KIT139HPS	Hardware Pack	1

Packing List (cont'd):

- KIT6C31MXPPZ	6-32 x 5/16" Screw	4
- KIT6CNKEPZ	6-32 Nut	4
- KIT6NWSAPZ	#6 Flat Washer	4

Tools Required for this Installation:

Flat Head Screwdriver
Phillips Screwdriver

Installation Instructions. Read Me!

I DISCONNECT NEGATIVE (-) BATTERY CABLE

II Remove Factory Intake Assembly

- a) Unclip the factory air box lid.
- b) Loosen clamp connecting the factory air box lid to the air intake tube and remove the air box lid and factory air filter from the vehicle. (*Note: leave the factory air box base in place*) See Fig#1

III Airaid Intake System Pre-Installation Assembly

- a) Assemble Airaid Quick Fit cool air dam panels using the (4) 6/32 bolts, washers and nuts provided. See Fig#2

IV Airaid Intake System Installation

- a) Install the Airaid intake assembly in place of the factory air box. Refer to Fig#3
- b) Secure the factory intake tube to the Airaid cool air dam using the factory hose clamp.
- c) Mount the Airaid Premium Filter to the tube on the inside of the Airaid cool air dam and tighten the hose clamp. Refer to Fig#3
- d) Install weather strip onto the top ridge of the Airaid cool air dam (*Hint: start the install at the top corner of the cold air dam*) Refer to Fig#2 & Fig#3

V Finishing Up

- a) Inspect overall work and check hood clearance.
- b) Ensure that no foreign objects are in the intake path!
- c) Re-connect negative battery cable.

Synthamax Air Filters **do not** require oil. Service air filter as needed by cleaning with common non-petroleum all-purpose household cleaner and water. Simple Green®, Formula 409® or equivalent works great. Apply cleaner to outside of air filter and allow to soak. Then flush filter clean from the inside out with a garden hose and repeat steps if necessary. Do not apply high pressure water of air to clean filter. Allow filter to air dry and reinstall.

REV10/25/10

SynthaMax
Do Not Oil



Fig#2

