



INTAKE SYSTEMS



Installation Instructions
Part Number 860-348
Airaid Premium Filter
2008-10 Ford F-250 Thru
F-550 Super Duty
Powerstroke 6.4L

Parts List

#1 Airaid Premium Filter x1

Thank you for purchasing an Airaid Premium Filter. Contact Airaid @ (800) 498-6951 8:00 AM - 5:00 PM MST weekdays for questions regarding fit or instructions that are not clear to you. Your Airaid Premium Filter was carefully inspected and packaged. The air filter element is protected from direct exposure to water and debris, care should be taken not to drive through deep water. WATER INGESTION IS THE DRIVERS RESPONSIBILITY! The air filter is reusable and should be cleaned using the Airaid Filter Tune-Up Kit periodically.


Thank you for selecting AIRAID.




1. Unlatch the two factory clips on each side of the airbox and then remove the airbox lid.




2. Remove the factory air filter by gently prying it towards the passenger side of the airbox, and then lifting it straight up.



3. Insert the Airaid Premium Filter (#1) into the factory airbox.



4. Firmly press the air filter into the factory airbox. Make sure that the sealing edge is fully seated and flush with the edge all the way around the airbox.



5. Locate the "step" on the bottom of the factory airbox. Make sure that the tab on the air filter is aligned with it. Next, align the two side tabs on the air filter with the side of the factory airbox.



6. Reinstall the factory airbox lid and re-latch the two factory clips.

7. Double check your work!

Contact your nearest Airaid dealer for an Airaid Intake System for your car, truck or SUV.

Don't Forget Your AIRAID Filter Tune-Up Kit!



P/N 790-551 Aerosol Spray
P/N 790-550 Squeeze Spray

Instructions Revision
01/07/10

AIRAIID Filter Co. 2688 E Rose Garden Ln. Phoenix AZ 85050 (800) 498-6951 Airaidinfo@airaid.com www.airaid.com