


INSTRUCTION MANUAL

CAT-BACK STAINLESS SINGLE EXHAUST DODGE DAKOTA 4.7L 2WD

CLUB CAB, SHORT BED 2DR QUAD CAB, SHORT BED PART # 616596



ITEM	PART # Q	UANTITY	DESCRIPTION
A	788702S-1	1	SUPERFLOW STAINLESS MUFFLER
В	834-700592S	1	3" STAINLESS OVERAXLE TAILPIPE
С	101-50032RS-6	1	3" STAINLESS TURNOUT PIPE
D	500360	1	3 1/2" STAINLESS STEEL TIP
Е	OHD300	2	3" CLAMP
F	5757	1	2 ½" CLAMP

Thank you for purchasing our GIBSON EXHAUST SYSTEM for your vehicle. If you need further assistance, please do not hesitate to call our Technical Department at 1-800-528-3044, Monday through Friday, 8:00AM to 5:00PM.


EXHAUST INSTALLTIONS # 616596

WHEN INSTALLING THIS EXHAUST SYSTEM, MAKE SURE TO USE PROPER SAFTEY PRECAUTIONS. USE TECH STANDS TO SUPPORT YOU TRUCK, SET PARKING BRAKE, AND BLOCK THE TIRES. USE SAFETY GLASSES. **DO NOT WORK WITH HOT PIPES.**

SUGGESTED TOOLS:

HACKSAW, JACKSTAND,9/16"SOCKET, 1/2"WRENCH & SOCKET

LAYOUT THE EXHAUST SYSTEM ON THE FLOOR LIKE THE DRAWING AND COMPARE PART NUMBERS.




DO NOT REMOVE YOUR STOCK HEADPIPE.

UNCLAMP YOUR EXHAUST IN FRONT OF THE STOCK MUFFLER AND REMOVE. FOR EASIER REMOVAL OF THE FACTORY EXHAUST CUT BEHIND THE REAR OF THE MUFFLER. USE WD-40 ON ALL HANGERS & BOLTS. LEAVE ALL RUBBER GROMMETS IN PLACE.



INSTALL OVERAXLE
TAILPIPE #B AND
CONNECT TO THE
MUFFLER USING CLAMP
E. INSERT WELDED
HANGERS INTO
RUBBER GROMMETS.



INSTALL MUFFLER
ONTO THE STOCK
HEADPIPE. SUPPORT
THE MUFFLER USING A
JACK STAND. MUFFLER
INLET IS LOOKING
INTO LOUVERS. USE
CLAMP #F TO SECURE
MUFFLER. DO NOT
TIGHTEN.



NEXT CONNECT THE TURN OUT PIPE #C TO THE OVERAXLE PIPE USING CLAMP #E. DO NOT TIGHTEN.



WHEN YOU HAVE
EVERYTHING IN PLACE
TIGHTEN ALL BOLTS
AND CLAMPS. INSTALL
STAINLESS STEEL TIP.
TO CLEAN TIP USE
ALUMINUM OR
STAINLESS STEEL
CLEANER.

MAKE SURE YOU HAVE AT LEAST A 1" CLEARANCE FROM ALL BRAKE LINES, FUEL LINES, SHOCKS, TIRES, ETC.