

40485 - Vehicle Wiring Installation Instructions Ford Fiesta 2011

- 1. Open rear hatch/ trunk. Temporarily remove the rear threshold plate and partially remove the felt trunk liner to access the taillight connectors. Set aside all items removed being careful not to damage parts.
- 2. On the Driver's side, disconnect the vehicle wiring harness from the taillight socket. Plug the Hopkins[®] T-Connector end with the yellow wire in-between the mating plugs on the driver's side taillight socket and vehicle wiring harness.
- 3. On the driver's side, route the T-Connector end with the green wire to the passenger's side along the threshold and behind the felt liner. Disconnect the vehicle wiring harness from the taillight socket. Plug the Hopkins® T-Connector end with the green wire in-between the mating plugs on the passenger's side taillight socket and vehicle wiring harness.
- 4. On the driver's side, locate and secure the T-Connector black converter box with ny-ties (provided) to prevent damage or rattling and being careful to avoid areas that would cut or pinch the wires.
- 5. Locate a suitable grounding point near the black converter module to attach to vehicle's frame. Clean dirt, paint and rustproofing from area. Drill a 3/32" hole and secure white wire with ring terminal using self tapping screw (provided). Verify what is behind any surface prior to drilling to avoid damage to the vehicle. Do not drill into any exposed surfaces.
- 6. Reinstall the rear threshold plate, felt trunk liner and any other items removed during installation.
- 7. Route the 4-way flat harness to either side of the receiver hitch and secure it with ny-ties.
- 8. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
- 9. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
- 10. Plug completed wire harness into the trailer 4-way flat connector.
- 11. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com