



## **43135 - Vehicle Wiring Installation Instructions**

### ***Honda Accord 2 Dr. 2003-05***

1. Open trunk and remove threshold panel. Partially remove the felt trunk liner on the driver's side and passenger's side exposing the taillight wiring.
2. Separate the taillight harness connectors, being careful not to break the locking tabs.
3. The taillight wiring harness will have connection points matching the ends of the Hopkins® T-connector with converter module.
4. On the driver's side, insert the T-Connector end, with the yellow wire, between the vehicle wiring connectors and lock into place. Next insert the T-Connector end, with the red wire, between the vehicle wiring connectors and lock into place. Ensure that the connectors are fully inserted with locking tabs in place.
5. On the driver's side, secure the converter module in the taillight area using ny-ties. (Provided)
6. On the driver's side, route the T-Connector end with the green wire to the passenger's side along the threshold and behind the trunk liner. Disconnect the vehicle wiring harness from the taillight socket. Plug the Hopkins® T-Connector end with the green wire in-between the mating plugs on the passenger's side taillight socket and vehicle wiring harness.
7. Locate a suitable position on the vehicle frame close to the connector to attach the convertor's white wire with the ring terminal. Drill a 3/32" hole and attach the white wire to the vehicle using the screw provided. Caution: Do not drill into any exposed surfaces or through the vehicle body exterior.
8. Re-install the trunk liner and reattach the threshold panel.
9. Route the 4-way flat harness to either side of the receiver hitch.
10. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
11. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
12. Plug completed wire harness into the trailer 4-way flat connector.
13. Test all functions with the engine running to ensure proper operation.
14. Store 4-flat in trunk area when not in use.

#### **TIPS:**

Grease applied to the trailer wiring terminals on a regular basis will help prevent corrosion.

A heavy duty flasher may be required to eliminate rapid flashing.

Always unplug boat trailer connector before backing trailer into the water.

**Need Help? (English Only)**  
**1-800-835-0129**  
**techsupport@hopkinsmfg.com**  
**www.hopkinstowingsolutions.com**