



43325 - Vehicle Wiring Installation Instructions 7 RV Blade and 4-Wire Flat Multi-Tow[®] Harness Toyota Sequoia 2005 - 2008

1. Locate the (2) vehicle 7-way RV wiring harness plugs at the rear of vehicle above the factory 7-Way RV socket assembly, slightly towards the drivers side. This connector harness will have the same connector ends as the Hopkins[®] MT-Connector.
2. Disconnect the vehicle 7-way RV wiring harness plugs (2). Connectors will disconnect by pressing or lifting on a locking tab and pulling apart.
3. Remove factory 7-way RV socket from vehicle 7-way mounting bracket.
4. Insert the Hopkins MT-Connector into the vehicle 7-way mounting bracket and secure with mounting bolts (Provided) or mount Hopkins 7-way mounting bracket and secure w/mounting bolts. (Provided)
5. Route the wire harness from the Hopkins MT-Connector to the (2) vehicle plugs. Connect the plugs making sure the connectors are fully inserted
6. Plug trailer connector/s into 4-way and 7-way receptacles and test all functions with the engine running to ensure proper operation.

TIPS:

Grease should be applied to the wiring terminals on a regular basis to help prevent corrosion.

A heavy duty flasher may be required to eliminate rapid flashing.

Always unplug boat trailer connector before backing trailer into the water.

**Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com**