



43875 - Vehicle Wiring Installation Instructions

Subaru Baja 2002- 2006

1. To access vehicle taillight wiring harness plug, go underneath the passenger side rear of vehicle, near the vehicle vapor canister to locate the 6 pin vehicle wiring connector.
2. Remove the existing vehicle connector plug cap.
3. Install the Hopkins® 6 pin wiring harness plug into the exposed connector.
4. Route the Hopkins converter module 6 pin end of the wiring harness around the passenger side tow hook and connect it to the 6 pin vehicle connector.
5. Secure the converter module block at a convenient location between the vehicle 6 pin plug and the receiver hitch.
6. Route the converter module 4-way flat extension harness over the hitch cross tube approximately 2 inches towards the passenger side of the hitch.
7. Secure the 4-way flat connector end of harness to an area near the receiver hitch with ny-ties provided in the accessory bag.
8. Attach the 4-way flat dust cover provided in the accessory bag to the 4-way flat connector.
9. Apply a small amount of grease provided in the accessory bag to the 4-way flat terminals to prevent corrosion.
10. Plug completed wire harness into the trailer 4-way flat connector.
11. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com