

The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The red wire in the harness will only be used in the 2007 CHEVROLET AVEO.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.

REV. 09/01/06 INST70-2105



The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The red wire in the harness will only be used in the 2007 CHEVROLET AVEO.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.

REV. 09/01/06 INST70-2105



The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The**

Varo

red wire in the harness will only be used in the 2007 CHEVROLET AVEO. All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.

REV. 09/01/06 INST70-2105



The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The red wire in the harness will only be used in the 2007 CHEVROLET AVEO.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.

REV. 09/01/06 INST70-2105



The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The red wire in the harness will only be used in the 2007 CHEVROLET AVEO.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.



The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The red wire in the harness will only be used in the 2007 CHEVROLET AVEO.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.



The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The red wire in the harness will only be used in the 2007 CHEVROLET AVEO.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.



The 70-2105 comes with both a red wire in the harness and also a loose red wire. **The red wire in the harness will only be used in the 2007 CHEVROLET AVEO.** All other applications will tape off the red wire in the harness and use the loose red wire supplied. You must run one end of the loose red wire to a 12 volt accessory wire or fuse either under the steering column or fuse box, and the other end to the aftermarket radios 12 volt accessory lead.