



951 Aiken Road • Owosso, MI 48867
989-725-8354 • Fax 989-725-8409
1-800-433-3604



Installation Kit No.: LIK-22
Contents: (2) Plastic Plugs

INSTALLATION INSTRUCTIONS

- Step 1:** Remove the Tailgate screws located in the center of metal Truck Tailgate.
- Step 2:** Place plastic Tailgate Liner onto metal Truck Tailgate and align holes.
- Step 3:** Re-insert the original Tailgate screws into the holes; do NOT tighten.
- Step 4:** Locate the "TABS" on either side of plastic Tailgate Liner; fold down along side of metal Tailgate.
- Step 5:** Insert plastic plugs into the holes located on the sides of the metal Tailgate which align with the holes in the plastic "TABS".
- Step 6:** Finish tightening the Tailgate screws located in the center of Tailgate; again do not overtighten.

