



Standard high back seat (13401.XX)  
Standard low back seat (13400.XX)  
1976 - 2002 CJ - Wrangler  
Installation Instructions

**13400.XX**  
Low Back



**13401.XX**  
High Back



**Included components:**

- (1) Lower seat section
- (1) Upper seat section
- (4) Hex Head Bolts
- (4) Lock Washers

**Seat Assembly:**

**Step (1)** Insert upper seat section to lower seat section through slots located on the back side of lower section.

**Step (2)** Fold upper section back into upright position. Turn seat over and pull plastic retainer channel away.

**Step (3)** Install all 4 bolts and washers (DO NOT TIGHTEN) After all bolts have been installed tighten and reinstall plastic retainer channel as shown above.

**Seat installation instructions:**

**Step (4)** Remove old seat from riser by removing 4 bolts. Save these bolts as they will be reused later.

**Step (5)** Remove sliders from old seats by removing 4 bolts. Save these bolts as they will be reused later.

**NOTE: To access the rear 2 bolts push slider arm down and move slider forward.**

**Step (6)** Place sliders onto new seats. Reuse spacers from the old seat to align the slider.

**Step (7)** Fasten slider to the new seat using the 4 bolts saved from step 5

**Step (8)** Carefully place slider back onto seat riser and fasten with 4 bolts saved from step 4

