

HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1 Position the hood protector in place by sliding the mounting tabs of the hood protector behind the rubber seal, lining up the holes with the holes in the hood. Using the screws with flat washers, attach the hood protector to the hood. Tighten just enough to hold the hood protector in place.
- 2 Close the hood **CAREFULLY** to check the fit. If the hood protector is not centered, slightly loosen the screws and move it to one side or the other until it is centered. When you are satisfied the hood protector is in place, tighten the screws until snug. **DO NOT OVER TIGHTEN this may damage your new hood protector.**

KIT CONTAINS:

HOOD PROTECTOR
6 MOUNTING SCREWS
6 WASHERS

TOOLS NEEDED:

PHILLIPS SCREWDRIVER

CLEANING:

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS.

IMPORTANT INFORMATION

AFTER INSTALLING THE HOOD PROTECTOR CHECK FOR FIT. MAKE SURE THE HOOD PROTECTOR IS NOT TOUCHING THE PAINT IN ANY SPOTS THAT MAY CAUSE RUBBING BY VEHICLE VIBRATION AS THIS INDICATES AN IMPROPER INSTALLATION. IF YOUR APPLICATION REQUIRES BUMP-ONS MAKE SURE THEY ARE INSTALLED PROPERLY.

STAMPEDE WILL NOT PAY FOR PAINT TOUCH UPS OR REPAIRS ON HOODS DUE TO IMPROPER INSTALLATION.

IF YOU HAVE A PRODUCT THAT USES 3M REDLINE AND HAVE TROUBLE REMOVING THE RED BACKING, USE A DROP OF ISOPROPAL ALCOHOL OR NAPHTHA ON THE EDGE OF THE BACKING AND THIS WILL ALLOW THE BACKING TO LOOSEN THUS ALLOWING YOU TO PEEL THE BACKING OFF THE TAPE.