

**IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT !**

- 1** HOLD THE HOOD PROTECTOR IN PLACE AND FAMILIARIZE YOURSELF WITH THE FIT.
- 2** LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS. WITH THE ALCOHOL PAD PROVIDED CLEAN THE AREAS UNDER THE HOOD WHERE THE TAPED MOUNTING TABS ARE TO ADHERE WAIT APPROX. 30 SEC FOR THE ALCOHOL TO DRY THEN APPLY THE ADHESIVE PROMOTER TO THE SAME AREA.
- 3** FIND THE L BRACKETS AND THE METAL CLIPS FROM THE HARDWARE PACK AND PLACE THE METAL CLIPS ONTO THE SHORT ENDS OF THE L BRACKETS WITH THE ANGLED END TOWARDS THE INSIDE OF THE L AS SHOWN (fig 1)
- 4** LOCATE THE BOLTS ON THE UNDERSIDE OF THE HOOD IMMEDIATELY TO THE LEFT AND TO THE RIGHT OF THE CENTER BOLT, AND REMOVE THE NUTS FROM THEM.
- 5** PLACE THE LONG SIDE OF THE L BRACKET ONTO THE BOLTS THROUGH THE TOP HOLE WITH THE CLIPS TOWARDS THE FRONT OF THE VEHICLE. (fig 1). REPLACE THE NUTS ONTO THE BOLTS.
- 6** CENTER THE HOOD PROTECTOR ON THE HOOD AND INSERT THE 2 SCREWS THROUGH THE CENTER HOLES IN THE MOUNTING TABS INTO THE HOLES OF THE L BRACKET, TIGHTEN UNTIL SNUG.
- 7** REMOVE THE RED BACKING FROM THE ADHESIVE STRIPS ON THE HOOD PROTECTOR MOUNTING TABS.
- 8** ONCE YOU ARE SURE OF THE PLACEMENT APPLY FIRM PRESSURE TO SECURE THE TABS TO THE UNDERSIDE OF THE HOOD AND TIGHTEN THE NUTS OF THE CENTER HOLES WHICH ARE ATTACHED TO THE L BRACKETS **DO NOT OVER TIGHTEN.**

CLOSE THE HOOD **CAREFULLY** TO CHECK THE FIT.

**CLEANING:** USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

**KIT CONTAINS:**  
HOOD PROTECTOR  
2 CLIPS  
2 L BRACKETS  
2 WASHERS  
2 SCREWS  
ALCOHOL PAD  
ADHESIVE PROMOTER

**TOOLS NEEDED:**  
7/16" SOCKET WRENCH

Fig 1

