

HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1 Lift the hood and remove any dirt or debris.
- 2 Hold the hood protector in place on the vehicle and note which 2 factory clips need to be removed for installation and remove the clips.
- 3 Place the 4 clips from the hardware pack into the outer holes.
- 4 Hold hood protector into place and slide the center mounting tabs between the factory rubber seal and the hood.
- 5 Center the shield to the hood, and using the screws from the hardware pack with washers attached, fasten the shield to the hood. Carefully lower the hood and check the alignment. If the hood protector is not centered, slightly loosen the screws and move it to one side or the other until centered and re-tighten the screws.

KIT CONTAINS:

HOOD PROTECTOR
4 PLASTIC CLIPS
4 MOUNTING SCREWS
4 WASHERS

TOOLS NEEDED:

PHILLIPS SCREWDRIVER

CLEANING:

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.