

# NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1** LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2** REMOVE THE RUBBER SEAL FROM THE UNDERSIDE OF THE HOOD.
- 4** LINE UP THE HOOD PROTECTOR ON THE UNDERSIDE OF THE HOOD. INSERT THE SCREWS THROUGH THE HOLES IN THE RUBBER SEAL, THE HOOD PROTECTOR AND INTO THE HOLES IN THE HOOD. **TIGHTEN JUST ENOUGH TO HOLD HOOD PROTECTOR IN PLACE.** (Fig 1)
- 5** CENTER THE HOOD PROTECTOR ON THE HOOD AND THEN TIGHTEN THE SCREWS WITH SCREWDRIVER UNTIL SNUG. **DO NOT OVER TIGHTEN** THIS MAY DAMAGE YOUR NEW HOOD PROTECTOR. CLOSE THE HOOD CAREFULLY TO CHECK THE FIT. IF THE HOOD PROTECTOR IS NOT CENTERED, SLIGHTLY LOOSEN THE SCREWS AND MOVE IT TO ONE SIDE OR THE OTHER UNTIL CENTERED AND RE-TIGHTEN THE SCREWS.
- 6** PUT A CLIP BACK IN EACH OF THE HOLES NOT BEING USED FOR THE INSTALLATION OF THE HOOD PROTECTOR.

**CLEANING:** USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

**KIT CONTAINS:**

HOOD PROTECTOR  
6 MOUNTING SCREWS  
6 SHOULDER WASHERS

**TOOLS NEEDED:**

PHILLIPS SCREWDRIVER

