

55244

NISSAN XTERRA

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

03/04/09

English

1. Locate the vehicles factory tow harness it will be located under the vehicle, behind the rear bumper on the passenger side location S7. [A](#)
2. Remove the protective cap and insert the 4-pin connector into the vehicles factory tow harness making sure the locking tab is in place.
3. Route the 4-Flat wire along the backside of the bumper to the center of the vehicle making sure to avoid areas that may pinch or cut the wire. Secure any loose wire with the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.