

55331

HONDA PASSPORT
IZUZU RODEO

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

01/22/09



English

1. Locate tow vehicle's trailer harness connector. This harness is located under the vehicle, behind the rear bumper, on the passenger side of the vehicle. (Location S6.)
2. Remove protective cap (and save) from connector, being careful not to break the locking tabs.
3. Connect the harness end to the vehicle's connector. Be sure that the T-connector is fully inserted with locking tabs in place. [B]
4. Route 4 flat to center of bumper and secure loose wires with cable ties provided. Attach black converter box on a clean flat surface under the vehicle.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surfaces before drilling to avoid damage to vehicle and/or personal injury.

Español

Français



55331