



# INSTALLATION / SAFETY INSTRUCTIONS

## Step 1

Access the vehicle wiring harness connectors in the trunk behind the taillight in positions P3 and P4 as shown in the 'Wiring Location Guide'.

## Step 2

Locate the vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

## Step 3

Open the trunk. Remove all trunk floor coverings (A). Remove the scuff panel by pulling out on the bottom and then up (B).

## Step 4


Remove the plastic push fasteners holding the felt trunk liner in place (C).

## Step 5

On the driver side, pull back on the felt trunk liner to locate the vehicle taillight wiring harness connectors (D). The connectors will be similar to those on the T-connector harness. Separate the connectors from the taillight housing, taking care not to damage the locking tabs (E).

## Step 6

Insert the T-connector end with the yellow wire between the separated 3-pin connectors. Insert the T-connector end with the red wire between the separated 4-pin connectors. Make sure the connectors are fully-inserted with locking tabs in place (F).

 **WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 7

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

## Step 8

Inside the vehicle, locate a flat spot and adhere the black converter box using the provided double-sided tape (F).

## Step 9

Route the T-connector end with the green wire to the passenger side behind the removed scuff panel. Repeat Steps 4-6 on the passenger side using the T-connector end with the green wire. Use the provided cable ties to secure any loose wires.

## Step 10

Route the black power wire from the vehicle battery as shown on the included CME-PCL-INS sheet.

## Step 11

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location.

## Step 12

Reinstall all items removed during install and reconnect the negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

