NISSAN SENTRA 2.0

3/22/2016

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 2,000 LBS. TRAILER WEIGHT & 200 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY AUXILIARY STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

TEM QTY PART NUM 1 2 1/2-13 x 1 1/2 2 2 7/16-14 x 1 3 2 CM-SP7 4 2 7/16-14 5 2 HFN 1213 6 2 7_16 FISHWIRE 7 1 11370-TPS	16-14 x 1	INSERT COILED END OF FISHWIRE TOOL THROUGH HITCH MOUNTING HOLE IN VEHICLE FRAME RAIL AND OUT THE ACCESS HOLE PASS COILED END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE TO KEEP SPACER SEPERATE FROM BOLT AS SHOWN. PULL PISHWIRE, SPACER, AND BOL T THROUGH FRAME AND OUT MOUNTING HOLE, USE FISHWIRE TO GUIDE HITCH DURING MOUNTING AND PREVENT LOSS OF BOLT /
2 2 7/16-14 x 1 3 2 CM-SP7 4 2 7/16-14 5 2 HFN 1213 6 2 7_16 FISHWIRE	16-14 x 1	AND OUT THE ACCESS HOLE PASS COILED END OF FISHWIRE THROUGH SPACER AND THREAD BOLT INTO COIL. KINK WIRE TO KEEP SPACER SEPERATE FROM BOLT AS SHOWN. PULL PISHWIRE, SPACER, AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE, AND OUT MOUNTING HOLE, NOSE FISHWIRE TO GUIDE NOLET HOLE NOUNTING TO GUIDE
3 2 CM-SP7 4 2 7/16-14 5 2 HFN 1213 6 2 7_16 FISHWIRE	M-SP7 .250 x 1.00 x 2.00" SQUARE HOLE SPACER 16-14 HEX FLANGE NUT FN 1213 HEX FLANGE NUT _16 FISHWIRE 7/16" FISHWIRE	THREAD BOLT INTO COIL. KIMK WIRE TO KEEP SPACER SEPERATE FROM BOLT AS SHOWN. PULL FISHWIRE, SPACER, AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE, USE FISHWIRE TO GUIDE HOLE HOLE HOLE HOLE HOLE HOLE HOLE HOL
4 2 7/16-14 5 2 HFN 1213 6 2 7_16 FISHWIRE	16-14 HEX FLANGE NUT FN 1213 HEX FLANGE NUT _16 FISHWIRE 7/16" FISHWIRE	BOLT AS SHOWN. PULL FISHWIRE SPACER. AND BOLT THROUGH FRAME AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE HOLE HOLE HOLE HOLE HOLE HOLE HOLE HOL
5 2 HFN 1213 6 2 7_16 FISHWIRE	FN 1213 HEX FLANGE NUT _16 FISHWIRE 7/16" FISHWIRE	FISHWIRE, SPACER, AND BOLITHROUGH FRAME AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE
6 2 7_16 FISHWIRE	_16 FISHWIRE 7/16" FISHWIRE	AND OUT MOUNTING HOLE. USE FISHWIRE TO GUIDE MOLE MOLE
		LUNGIL DUDING AND MADE AND DEPURE A DESCRIPTION OF DELL'S
7 1 11370-TPS	370-TPS .250" TRUNK PAN SPACER	SPACER INSIDE FRAME RAIL
		"NOTE: SOME VEHICLES MAY FISHWIRE THROUGH END OF FRAME"
6	TRUNK PAN	HOLE ENLARGEMENT REQUIRED FOR INSTALL DESIGNED FOR USE EURO BALL MOUNT 45561 (1 7/8" BALL) OF 45562 (2" BALL)

INSTALLATION STEPS

-SPARE TIRE REMOVAL REQUIRED

PROFESSIONAL: 30 MINUTES NOVICE (DIY): 60 MINUTES

INSTALL NOTES:
-DRILLING REQUIRED
-FISHWIRING REQUIRED

- 1) Remove spare tire from trunk, remove rubber plugs.
- 2) Install trunk pan spacer with (2) 1/2" carriage bolts.
- 3) Enlarge two holes in bumper beam which line up with outer two holes in hitch plate.
- 4) Fishwire (2) 7/16" carriage bolts with SP7 spacers from end of bumper beam to enlarged holes.
- 5) Raise hitch into position and finger tighten in place with (2) 1/2" and (2) 7/16" flange nuts.
- 6) Torque all 7/16" hardware to 70 ft.-lb. and all 1/2" hardware to 110 ft.-lb.
- 7) Return spare tire to trunk.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

DESIGNED FOR USE WITH BALL MOUNT # D-20 / 45520

Curt Manufacturing Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.