



WEATHERBEATER™ FLOOR LINERS

PT #25281

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater™ Cargo Liner from Husky Liners. Your new cargo liner is custom molded to fit the trunk of your vehicle. Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the cargo area of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this “relaxing” may take longer; moving the liner to a heated area and letting it lay face-down in a flat position will speed the process.

Your liner is manufactured using an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Do not use Armor All®, Son-of-a-Gun® or similar items as these products make the liner slick.





WEATHERBEATER™ FLOOR LINERS

PT #25281

1. The 3rd row seats must be all the way in the back position. Fig. 1.
2. The 3rd row seatbacks must be in the lowered position. Fig. 1.
3. The shelf must be in the 2nd position up from the bottom. Fig. 1.
4. Both flaps on the shelf must be deployed and resting on the back of the 3rd row seats. Fig. 2.
5. Install the Upper Tray in the shelf/flap/seatback area. Fig. 3.
6. Install the Lower Tray in the bottom of the cargo area. Fig. 3.

FIG. 1



FIG. 2



FIG. 3

