



# X-ACT CONTOUR

## FLOOR LINERS

### CARE AND USE INSTRUCTIONS – PN:53911

---

Thank you for selecting a X-act Contour Floor Liner from Husky Liners Inc. Your new rear floor liner is custom molded to fit your Chevrolet Silverado/GMC Sierra Double Cab truck. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

### INSTALLATION INSTRUCTIONS FOR YOUR CHEVROLET SILVERADO & GMC SIERRA DOUBLE CAB TRUCK 2ND SEAT FLOOR LINER



TO EASE INSTALLATION OF YOUR DOUBLE CAB TRUCK SECOND SEAT LINER, MOVE BOTH OF THE FRONT ROW SEATS TO THEIR MOST FORWARD POSITION AND FLIP UP THE 2<sup>ND</sup> ROW SEAT BOTTOMS. WITH THIS DONE, INSTALL YOUR LINER, POSITIONING IT AS SHOWN IN THE IMAGE ABOVE. ONCE THE LINER IS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED AND LOWER YOUR 2<sup>ND</sup> ROW SEATS.

YOUR LINER IS DESIGNED TO ALLOW THE HUSKY LINER GEARBOX™ PART #09041 TO BE MOUNTED TOP OF THIS LINER.