



**ADVENTURE
FURTHER®**

**DITCH MOUNT
19+ MERCEDES SPRINTER VAN
73444 | 59-00213-01**

INSTALLATION INSTRUCTIONS

IMPORTANT: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



TOOLS NEEDED: 13MM WRENCH



1 IDENTIFY DRIVER & PASSENGER SIDE BRACKETS AND MAKE SURE TO INSTALL ONE SIDE AT A TIME TO ENSURE HOOD ALIGNMENT. WITH THE HOOD UP, BEGIN BY MANEUVER THE DITCH MOUNT BRACKETS INTO POSITION 'OVER' THE FACTORY HINGE & STUDS.



2 SEAT THE BRACKET FLAT AGAINST THE FACTORY HINGE PLATE & STUDS - THE BRACKET WILL CLICK INTO PLACE TO INDICATE CORRECT ALIGNMENT.

INSTALLATION INSTRUCTIONS



USING THE SUPPLIED WASHER AND NYLOCK NUT, SECURELY FASTEN THE DITCH MOUNTS TO THE HINGE.



REPEAT THE DITCH MOUNT INSTALLATION STEPS TO THE OTHER SIDE. DOUBLE-CHECK TO MAKE SURE EVERYTHING IS SECURE; AND THEN INSTALL THE LIGHTS OF YOUR CHOOSING.