



INSTALLATION INSTRUCTIONS

IMPORTANT:

Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



PARTS INCLUDED:
(Lights are sold separately)

QTY 2 - Ditch Mounts

**TOOLS NEEDED FOR
INSTALLATION:**

Wrench Set

STEP BY STEP INSTALLATION INSTRUCTIONS

Only install one side at a time to ensure hood alignment is maintained.

1. Remove windshield wipers.
2. Remove the two corner caps on the cowling. ****THESE WILL NOT BE REPLACED!****
3. Unscrew the two screws that are securing the cowling in place.
4. Carefully pry up the clips. ****DO NOT RUSH OR YOU MAY DAMAGE OR BREAK THE CLIPS.****
5. Remove the front lower hinge hood bolt.
6. Place the bracket over the two factory hole locations. Using the bolts provided, replace the factory hinge bolts.
7. Once brackets clear the area, reinstall the cowling.
8. Relocate the windshield wiper hose so it does not become pinched.
9. Double check hood clearance.
10. Reinstall wipers.