



# NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

#12

**IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT! (See Insert)**

- 1** Lift the hood and remove any dirt or debris.
- 2** Hold the hood protector in place and familiarize yourself with the fit. Take note of where the adhesive will make contact with the hood and clean **THOROUGHLY** with the alcohol pads provided.
- 3** Center the hood protector on the hood. Remove the red backing from the tape working from the outside edges to the center.
- 4 CAUTION:** *Once the Hood Protector is in place it cannot be repositioned without possible damage.*  
Press firmly along the taped portion with the palm of your hand to ensure proper adhesion. Close the hood carefully to check the fit.

**KIT CONTAINS:**  
HOOD PROTECTOR  
ALCOHOL PREP PADS

**CLEANING:** USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Products, Inc. • 1924 S. Washington, Blvd. • Camanche, IA. 52730 • Ph 563-259-9189 Fax 563-259-9288 • [www.stampedeproducts.com](http://www.stampedeproducts.com)