



STAMPEDE
TRUCK ACCESSORIES

HOOD PROTECTOR INSTALLATION INSTRUCTIONS

#24

- 1** OPEN HOOD SO THE UNDERSIDE IS VISIBLE.
- 2** INSERT PLASTIC BUSHINGS INTO THE FOUR EXISTING HOLES LOCATED ON THE UNDERSIDE OF HOOD.
- 3** USING THE ALCOHOL PADS FROM THE HARDWARE PACK CLEAN THE UNDERSIDE OF YOUR HOOD WHERE THE TWO STRIPS OF DOUBLE SIDED TAPE NEED TO ADHERE.
- 4** SLIDE A PLASTIC WASHER ONTO EACH OF THE SCREWS FROM YOUR HARDWARE PACK. REMOVE RED BACKING FROM THE TAPE LOCATED ON THE OUTER TWO TABS OF YOUR HOOD PROTECTOR.
- 5** CAREFULLY, WITHOUT APPLYING TOO MUCH PRESSURE, CENTER THE HOOD PROTECTOR TO THE UNDERSIDE OF THE HOOD. ONCE YOU HAVE IT WHERE IT NEEDS TO BE APPLY PRESSURE TO THE TABS THAT ARE TO BE TAPED.
- 6** WITH A #2 PHILLIPS SCREWDRIVER CAREFULLY ATTACH THE TABS WITH THE SCREWS FROM THE HARDWARE PACK THAT YOU PLACED THE SHOULDER WASHERS ON. DO NOT OVER TIGHTEN!!!!

KIT CONTAINS:

HOOD PROTECTOR
5 PLASTIC CLIPS
5 LARGE MOUNTING SCREWS
5 WASHERS
ALCOHOL PAD

TOOLS NEEDED:

PHILLIPS SCREWDRIVER

CAUTION!!

DO NOT ATTEMPT TO USE POWER TOOLS WHEN INSTALLING YOUR HOOD PROTECTOR. THIS WILL CAUSE THE THREADS TO STRIP INSIDE THE PLASTIC GROMMETS.

CLEANING:

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.