



# HOOD PROTECTOR INSTALLATION INSTRUCTIONS

**TOOLS NEEDED:**  
5/16" Nut Driver

- 1 LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2 REMOVE THE 6 NUTS FROM THE GRILL STUDS AND THE 6 SCREWS THAT ATTACH THE GRILL SUPPORT FRAME TO THE HOOD USING A 5/16" NUT DRIVER
- 3 CAREFULLY LOWER THE HOOD AND SEPARATE THE GRILL FROM THE HOOD JUST ENOUGH SO THAT THE HOOD PROTECTOR WILL SLIDE BETWEEN THE GRILL AND THE HOOD.
- 4 WHEN THE HOOD PROTECTOR IS IN PLACE, CAREFULLY RAISE THE HOOD AND REINSTALL THE NUTS ON THE STUDS AND TIGHTEN. (DO NOT OVER TIGHTEN!) THEN REINSTALL THE SCREWS INTO THE GRILL SUPPORT FRAME.
- 5 LOWER AND LATCH THE HOOD AND CHECK TO MAKE SURE THE HOOD PROTECTOR IS FIRMLY IN PLACE AND CENTERED.

# FENDER SECTION INSTALLATION INSTRUCTIONS

**KIT CONTAINS:**

2 HOOD PROTECTOR (FENDER SECTIONS)  
ALCOHOL PAD

**TOOLS NEEDED:**

PHILLIPS SCREWDRIVER

- 1 Raise the hood of the vehicle. On each fender there is a black rubber seal held on by three plastic clips. Using a phillips screwdriver, remove the center of each clip and remove the clips from the seals.
- 2 Hold the fender protector up to the fender and take note where the adhesive will make contact. Clean the area with the alcohol pad provided.
- 3 Remove the red liner from the tape. Slide the fender protector **behind** the rubber seal and reinstall the plastic clips through the seal, the fender protector and into the fender.
- 4 Carefully slide the taped edge of the fender protector between the fender and headlight. Line up the taped edge on the protector with the leading edge of the fender, and apply upward pressure on the protector to secure the adhesive in place.

**CLEANING:** USE ONLY WARM SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS, OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR!