


- 1** LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2** PUSH THE PLASTIC INSERTS INTO THE EXISTING FACTORY HOLES ON THE UNDERSIDE OF THE HOOD. SNAP INTO PLACE WITH YOUR THUMB OR THE END OF A SCREWDRIVER.
- 3** USING THE ALCOHOL PADS FROM THE HARDWARE PACK CLEAN THE UNDERSIDE OF THE HOOD WHERE THE ADHESIVE STRIP WILL MEET THE HOOD.
- 4** REMOVE THE RED BACKING FROM THE ADHESIVE STRIP ON THE HOOD PROTECTOR. CENTER THE HOOD PROTECTOR ON THE HOOD AND LINE UP THE MOUNTING HOLES WITH THE PLASTIC INSERTS.
- 5** ONCE YOU ARE SURE OF THE PLACEMENT APPLY MODERATE PRESSURE TO HOLD IT IN PLACE AND INSERT THE SCREWS WITH THE WASHERS THROUGH THE HOLES IN THE HOOD PROTECTOR INTO THE PLASTIC INSERTS. TIGHTEN THE SCREWS WITH SCREWDRIVER UNTIL SNUG. **DO NOT OVER TIGHTEN** THIS MAY DAMAGE YOUR NEW HOOD PROTECTOR. CLOSE THE HOOD CAREFULLY TO CHECK THE FIT.

**KIT CONTAINS:**  
HOOD PROTECTOR  
2 MOUNTING SCREWS  
2 PLASTIC WASHERS  
2 PLASTIC INSERTS  
**TOOLS NEEDED:**  
PHILLIPS SCREWDRIVER



**CLEANING:** USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.