



NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

IDEAL TAPE APPLICATION TEMPERATURE RANGE IS 70-100 DEGREES FAHRENHEIT ! (see insert)

KIT CONTAINS:
HOOD PROTECTOR
ALCOHOL PADS

- 1** REMOVE THE 6 NUTS AND BOLTS THAT FASTEN THE GRILL ASSEMBLY TO THE HOOD. REMOVE AND SET ASIDE.
- 2** USING THE ALCOHOL PADS FROM THE HARDWARE PACK CLEAN THE UNDERSIDE OF THE HOOD WHERE THE ADHESIVE STRIP WILL MEET THE HOOD. REMOVE THE RED BACKING FROM THE STRIP.
- 3** CENTER THE HOOD PROTECTOR ON THE HOOD AND USING FIRM PRESSURE PRESS THE HOOD PROTECTOR TABS TO THE UNDERSIDE OF THE HOOD LIP. REINSTALL THE GRILL ASSEMBLY.

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

