

NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1** LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2** CENTER THE HOOD PROTECTOR ON THE UNDERSIDE OF THE HOOD. INSERT THE FASTENERS THROUGH THE HOOD PROTECTOR AND INTO THE HOLES IN THE HOOD.
- 3** CLOSE THE HOOD **CAREFULLY** TO CHECK THE FIT. IF THE HOOD PROTECTOR IS NOT CENTERED, SLIGHTLY LOOSEN THE FASTENERS AND MOVE IT TO ONE SIDE OR THE OTHER UNTIL CENTERED AND RE-TIGHTEN.

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

KIT CONTAINS:
HOOD PROTECTOR
4 PLASTIC FASTENERS
TOOLS NEEDED:
PHILLIPS SCREWDRIVER

