

NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1** HOLD THE HOOD PROTECTOR IN PLACE AND FAMILIARIZE YOURSELF WITH THE FIT. LIFT THE HOOD AND REMOVE ANY DIRT OR DEBRIS.
- 2** USING THE ALCOHOL PADS FROM THE HARDWARE PACK, CLEAN THE AREA ON THE UNDERSIDE LEADING EDGE OF THE GRILL WHERE THE ADHESIVE STRIPS ON THE MOUNTING TABS WILL ADHERE.
- 3** PLACE A GROMMET NUT INTO EACH OF THE FOUR FACTORY SLOTS ON THE UNDERSIDE OF THE HOOD LOCATED ABOVE THE HEADLIGHT AREA.
- 4** REMOVE THE RED BACKING FROM THE ADHESIVE STRIPS ON THE MOUNTING TABS. CENTER THE HOOD PROTECTOR TO THE GRILL AND ADHERE THE MOUNTING TABS TO THE UNDERSIDE LEADING EDGE OF THE GRILL OPENING. APPLY FIRM PRESSURE TO ENSURE PROPER ADHESION.
- 5** ATTACH THE OUTER MOUNTING TABS WITH THE SCREWS AND WASHERS FROM THE HARDWARE PACK. **DO NOT OVER TIGHTEN** THIS MAY DAMAGE YOUR NEW HOOD PROTECTOR. CLOSE THE HOOD CAREFULLY TO CHECK THE FIT.

KIT CONTAINS:
HOOD PROTECTOR
4 MOUNTING SCREWS
4 SHOULDER WASHERS
4 GROMMET NUTS
ALCOHOL PADS
TOOLS NEEDED:
PHILLIPS SCREWDRIVER

CLEANING: USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

CAUTION!

**DO NOT ATTEMPT TO USE POWER TOOLS WHEN INSTALLING YOUR HOOD PROTECTOR.
THIS MAY CAUSE THE THREADS TO STRIP INSIDE THE PLASTIC GROMMET NUTS.**