

## NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

- 1 Raise the hood and carefully remove the rubber seal. Set aside to be re-installed with the Hood Protector.
- 2 Position the Hood Protector on the hood and line up the holes in the mounting tabs with the existing holes in the hood.
- 3 Holding the Hood Protector in place, re-align the holes in the previously removed rubber seal with the corresponding holes in the hood. Use the provided push pins to attach the seal and the Hood Protector to the hood.

KIT CONTAINS:
HOOD PROTECTOR
4 PUSH PINS
TOOLS NEEDED:
SCREWDRIVER

4 Use the factory clips to re-install the remainder of the rubber seal to the hood.

#### **CLEANING:**

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Products, Inc. • 1924 S. Washington, Blvd. • Camanche, IA. 52730 • Ph 563-259-9189 Fax 563-259-9288 • www stampedeproducts.com



## NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

#96

- Raise the hood and carefully remove the rubber seal. Set aside to be re-installed with the Hood Protector.
- 2 Position the Hood Protector on the hood and line up the holes in the mounting tabs with the existing holes in the hood.
- 3 Holding the Hood Protector in place, re-align the holes in the previously removed rubber seal with the corresponding holes in the hood. Use the provided push pins to attach the seal and the Hood Protector to the hood.
- 4 Use the factory clips to re-install the remainder of the rubber seal to the hood.

### KIT CONTAINS:

HOOD PROTECTOR 4 PUSH PINS

**TOOLS NEEDED:** 

**SCREWDRIVER** 

#### **CLEANING:**

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Products, Inc. • 1924 S. Washington, Blvd. • Camanche, IA. 52730 • Ph 563-259-9189 Fax 563-259-9288 • www stampedeproducts.com



# NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

#96

- 1 Raise the hood and carefully remove the rubber seal. Set aside to be re-installed with the Hood Protector.
- 2 Position the Hood Protector on the hood and line up the holes in the mounting tabs with the existing holes in the hood.
- 3 Holding the Hood Protector in place, re-align the holes in the previously removed rubber seal with the corresponding holes in the hood. Use the provided push pins to attach the seal and the Hood Protector to the hood.

### KIT CONTAINS:

HOOD PROTECTOR
4 PUSH PINS
TOOLS NEEDED:

SCREWDRIVER

SCHLVVDRIVLN

4 Use the factory clips to re-install the remainder of the rubber seal to the hood.

#### **CLEANING:**

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.

Stampede Products, Inc. • 1924 S. Washington, Blvd. • Camanche, IA. 52730 • Ph 563-259-9189 Fax 563-259-9288 • www stampedeproducts.com

### STAMPEDE TRUCK ACCESSORIES

# NO DRILL HOOD PROTECTOR INSTALLATION INSTRUCTIONS

#96

- Raise the hood and carefully remove the rubber seal. Set aside to be re-installed with the Hood Protector.
- 2 Position the Hood Protector on the hood and line up the holes in the mounting tabs with the existing holes in the hood.
- 3 Holding the Hood Protector in place, re-align the holes in the previously removed rubber seal with the corresponding holes in the hood. Use the provided push pins to attach the seal and the Hood Protector to the hood.

HOOD PROTECTOR 4 PUSH PINS **TOOLS NEEDED:** SCREWDRIVER

KIT CONTAINS:

4 Use the factory clips to re-install the remainder of the rubber seal to the hood.

### **CLEANING:**

USE ONLY SOAPY WATER AND A SOFT CLOTH. NEVER USE PAPER TOWELS, PETROLEUM PRODUCTS OR SOLVENTS TO CLEAN YOUR HOOD PROTECTOR.