

For **2020** models, use bracket number 55-18-3590, adel clamp, and hardware provided to attach the OE brakeline to steering knuckle. The OE brakeline bracket must be removed. Use OE brakeline bracket hardware to attach 55-18-3590 to the steering knuckle.

