



# Windshield Header Installation Instructions



**For: International Scout II**

**Part Number: 51207**



## **WARNING**

This product is designed to enhance the appearance of the vehicle and to shield the occupants from ordinary weather conditions. Do not rely in any way on the components of this product to contain occupants within the vehicle, or to protect against injury or death in the event of an accident. This product will not protect the occupants from falling objects. Never operate vehicle in excess of manufacturer's specifications.


### **WEAR SEAT BELTS AT ALL TIMES**

Read and follow, precisely, all installation instructions provided when installing this product. Failure to do so may result in a poor fit and could place occupants of the vehicle in a potentially dangerous situation. Failure to properly install or reinstall this product may cause the top or a component part to come off the vehicle, potentially causing an accident and possible injury to the occupants of the vehicle. After installing or reinstalling the top, check to make sure it has been properly installed.

## **Installation Tips**

Before you begin installing this windshield header, read all instructions thoroughly. After completing the installation, keep these instructions for further reference.

## Parts List and Hardware Identification



### Tools Needed


Adjustable Wrench  
Safety Glasses

## Windshield Header Installation


### Step One

#### Install Windshield Header

Orient the two pieces of the Windshield Header on the windshield frame with the tab toward the outside of the vehicle. Align the holes in the header with the holes in the frame. Use the bolts from the factory hard top to secure the header to the frame. Tighten the bolts.



**Note:** If there is any weatherstripping along the top of the windshield frame it should be left in place.



**For Bestop Warranty Information, Please go to;**  
<https://www.bestop.com/help/warranty-information/>

