


SEAT COVERS  
BY



FEATURING  
SUPER-GRIP®  
**THE SLIP RESISTANT FASTENING SYSTEM**

**INSTALLATION INSTRUCTIONS  
FOR  
NP92-56/ Oe32-56/ SL62-56/ SP82-56/ TR42-56/ TRS42-56**

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

**A. CUSHION COVER**


- 1) Center cover on the seat
- 2) Tuck back flap through crevice
- 3) Lift seat and pass the front strap under seat and buckle
- 4) Adjust straps and buckles to equalize tension

**B. BACKREST COVER**


- 1) Undo Velcro on cover
- 2) Slip cover over headrest and backrest. Ensure cover is installed under seat belt strap.
- 3) Lift headrest and close Velcro on cover.
- 4) Feed the back straps behind the seat so they go all the way down. Due to restricted space, some assistance may be required. A 4" x 30" piece of cardboard with 2 slits at one end will simplify the placing of the straps. The cardboard strip can be cut from the seat cover box. (see note)
- 5) Smooth cover tightly from top to bottom, tuck bottom cover through crevice
- 6) With cushion in up position, locate strap and secure to buckle on cover
- 7) Install adhesive back velcro (included) on inside edge of armrest well to align with velcro on seat cover. **NOTE: BEFORE SECURING VELCRO, CLEAN AREA WITH ALCOHOL SWAB PROVIDED.**
- 8) Apply side velcro to bottom flap (see note below)
- 9) Repeat on other side
- 10) Adjust all velcro, straps and buckles to equalize tension and ensure a snug fit

**NOTES:**

- 1) SELF-LOCKING SUPER-GRIP® BUCKLE:



- 5) BOTTOM FLAP INSTALLATION



- 4) FEEDING BACK STRAPS ON BACKREST



WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438  
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com