

12090 INSTALLATION INSTRUCTIONS



Safety glasses should be worn at all times while installing this product.

YEARS: 2010-PRESENT

MAKE: BUICK, CADILLAC

MODEL: LACROSSE CXS,CXL, CADILLAC XTS

STYLE: SEDAN

WARNING: NEVER EXCEED YOUR VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY

WEIGHT CARRYING:

TRAILER WEIGHT: LBS. 3500 **TONGUE WEIGHT:** 350 LBS.

WE RECOMMEND THE USE OF 18050 STABILIZING STRAPS FOR ALL NON-TRAILER (WHEEL-LESS) LOADS. PLEASE SEE THE CURT CATALOG OR VISIT US ONLINE AT

WWW.CURTMFG.COM FOR FURTHER INFORMATION.

INSTALLATION TIME: 30 MIN.


THE INSTALL TIME LISTED IS FOR PROFESSIONAL INSTALLERS. IF YOU ARE HESITANT TO UNDERTAKE THIS TASK ON YOUR OWN, CONTACT AN AUTHORIZED CURT INSTALLER FOR ADDITIONAL ASSISTANCE.



INSTALLATION TIPS:

- 1. BEFORE YOU BEGIN INSTALLATION, READ ALL INSTRUCTIONS THOROUGHLY.
- 2. TO EASE INSTALLATION, 2 PEOPLE MAY BE REOUIRED.
- 3. USING PROPER TOOLS WILL GREATLY IMPROVE THE QUALITY OF THE INSTALL AND REDUCE THE TIME REQUIRED.
- 4. NEED HELP OR HAVE SOME QUESTIONS? CALL TECHNICAL SUPPORT AT 800.798.0813

LEVEL OF DIFFICULTY: **EASY**




VEHICLE PHOTO:



REPRESENTATIVE PHOTO

HITCH ILLUSTRATION:




MAKE SURE YOUR HITCH MATCHES

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE ALL FASTENERS ARE TIGHT AND ALL STRUCTURAL COMPONENTS ARE SOUND

CURT Manufacturing LLC. warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing LLC. may repair or replace the product at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing LLC's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.

INSTALLATION WALKTHROUGH:

Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	2	M8 - 1.25 x 30 HEX BOLT	HEX HEAD BOLT
2	4	1/2-13 x 1 1/2	CARRIAGE BOLT
3	1	1/2 - 13 x 1 1/2	HEX BOLT
4	5	HFN 1213	HEX FLANGE NUT
5	1	1/2"	LOCK WASHER
6	2	3/8"	CONICAL WASHER
7	1	3/8"	WASHER
8	1	3/8"	LOCK WASHER
9	1	RIVET NUT	3/8" LARGE FLANGE RIBBED NUTSERT
10	2	M8-1.25	HEX NUT
11	1	3/8-16 X 1 1/2	HEX BOLT
12	1	3/8"	3/8 EXTERNAL TOOTHED WASHER



1. Remove (1) 8mm bolt from the exhaust hanger bracket on each side of the vehicle, and clean weldnut.





2. Raise receiver tube section of hitch into place and use the 8mm bolts and conical toothed washers provided and secure into place.






For more information log onto www.curtmfg.com, & for helpful towing tips log onto www.hitchinfo.com


INSTALLATION WALKTHROUGH:

3. Enlarge the driver side hole in the suspension frame rail to 1/2".





4. Assemble the bolt on bracket as shown. Tighten 3/8" bolt to 30 lb-ft.





5. Loosely secure the 8mm nut to the back side of the frame bracket to hold the exhaust bracket in place. Torque 8mm hardware to 17 lb-ft.





6. Raise the center section of the hitch into place and secure the (5) 1/2" hardware that hold it into place. Torque 1/2" hardware to 75 lb-ft. Installation is complete.





For more information log onto www.curtmfg.com, & for helpful towing tips log onto www.hitchinfo.com

CADILLAC XTS, BUICK LACROSSE AWD, CXL, CXS

12/27/2012


GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3500 LBS. TRAILER WEIGHT & 350 LBS. TONGUE WEIGHT.

DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY 18050 STABILIZING STRAPS.

** FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY**

HAVING INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813



INSTALLATION STEPS

- 1. Remove (1) 8mm bolt from the exhaust hanger bracket on each side of the vehicle, and clean weldnut.
- 2. Raise receiver tube section of hitch into place and use the 8mm bolts and conical toothed washers provided and secure into place.
- 3. Enlarge the driver side hole in the suspension frame rail to 1/2". Place the rivet nut in the enlarged hole by lightly tapping it in to the hole.
- 4. Assemble the bolt on bracket in the same order as shown. Tighten 3/8" bolt to 30 lb-ft.
- 5. Loosely secure the 8mm nut to the back side of the frame bracket to hold the exhaust bracket in place. Torque 8mm hardware to 17 lb-ft.
- 6. Raise the center section of the hitch into place and secure the (5) 1/2" hardware that hold it into place. Torque 1/2" hardware to 75 lb-ft.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Curt Manufacturing LLC., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Curt Manufacturing LLC., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Curt Manufacturing LLC.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage.