



INSTALLATION INSTRUCTIONS FOR PART 99-9106

APPLICATIONS

AUDI
A4/A6/A8 1996-1999
A4 (with Concert Radio) 2001-2004
Audi TT 2001-2006

99-9106


KIT FEATURES

- DIN Radio Provision




KIT COMPONENTS


- A) Trim Plate (a) • B) Trim Plate (b) • C) Trim Plate (c)
- E) (2) Screw Caps



A



B




C



D

TOOLS REQUIRED:

- Radio Removal Tool Metra Part# 86-9001 • Flat Blade Screwdriver
- * Panel Removal Tool



1-800-221-0932



www.metraonline.com

© COPYRIGHT 2001-2008 METRA ELECTRONICS CORPORATION

TABLE OF CONTENTS

Dash Disassembly

- Audi A4/A6/A8 1996-1999..... 1
- Audi A4 (With Concert Radio) 2001-2004..... 1
- Audi TT 2001-2006..... 1

Final Assembly..... 2,3

Final Assembly Wiring..... 4

*Note:

Refer also to the instructions included with the aftermarket radio.





KNOWLEDGE IS POWER

Enhance your installation and fabrication skills by enrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps toward a better tomorrow.

AUDI A4/A6/A8 1996-1999
AUDI A4 (WITH CONCERT RADIO) 2001-2004
AUDI TT 2001-2006

**Note: Refer also to the instructions included with the aftermarket radio.*

- 1 Disconnect the negative battery-terminal to prevent an accidental short circuit.
- 2 Insert the long ends of the radio removal tools into the slots in the factory radio and pull the radio out. (Figure A)
- 3 Unplug and remove radio.
- 4 Remove (2) Phillips head screws from inside the radio opening. (TT models only) (Figure B)



Continue to final assembly.



FINAL ASSEMBLY

AUDI A4/A6/A8 1996-1999

**Note: Refer also to the instructions included with the aftermarket radio.*

- 1 Slide the DIN cage into the radio opening in the dash and secure by bending the locking tabs outward.
- 2 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter and making the connections as shown. (Isolate and individually tape off the ends of any unused wires to prevent electrical short circuit)
- 3 Re-connect the negative battery terminal and test the unit for proper operation.
- 4 Slide the radio into the DIN cage until it snaps into place.
- 5 Snap Trim Plate (a) onto the front of the radio.

AUDI A4 (WITH CONCERT RADIO) 2001-2004

**Note: Refer also to the instructions included with the aftermarket radio.*

- 1 Place Trim Plate (b) into the Radio Opening in the dash.
- 2 Slide the DIN cage into the radio opening thru the Trim Plate and secure by bending the locking tabs outward. Make sure the locking tabs catch both the edge of the Trim Plate and the dash.
- 3 Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter and making the connections as shown. (Isolate and individually tape off the ends of any unused wires to prevent electrical short circuit)
- 4 Re-connect the negative battery terminal and test the unit for proper operation.
- 5 Slide the radio into the DIN cage until it snaps into place.

FINAL ASSEMBLY

AUDI TT 2001-2006

**Note: Refer also to the instructions included with the aftermarket radio.*

- 1** Slide the DIN cage into the radio opening in the dash and secure by bending the locking tabs outward.

- 2** Locate the factory wiring harness in the dash. Metra recommends using the proper mating adapter and making the connections as shown. (Isolate and individually tape off the ends of any unused wires to prevent electrical short circuit)


- 3** Re-connect the negative battery terminal and test the unit for proper operation.

- 4** Slide the radio into the DIN cage until it snaps into place.

- 5** Secure Trim Plate (c) to the front of the radio opening using the screws removed during disassembly.

- 6** Place the Screw Caps into the screw openings in the Trim Plate.
Enjoy your new radio.

FINAL ASSEMBLY WIRING



(A) Strip wire ends back 1/2"

B) Twist ends together

C) Solder

D) Tape

FINAL WIRING CONNECTIONS

Make wiring connections using the EIA color code chart shown below and the instructions included with the head unit. Metra recommends making connections as shown below; Strip, Splice, Solder, Tape. Isolate and individually tape off ends of any unused wires to prevent electrical short circuit.

METRA / EIA WIRING CODE

12V Ignition / Acc. Red	Right Front (+) Gray
12V Batt / Memory Yellow	Right Front (-) Gray/ Black
Ground Black*	Left Front (+) White
Power Antenna Blue	Left Front (-) White / Black
Amp Turn-On Blue / White	Right Rear (+) Violet
Amp Ground Black / White	Right Rear (-) Violet / Black
Illumination Orange	Left Rear (+) Green
Dimmer Orange / White	Left Rear (-) Green / Black

***NOTE:** When a Black wire is not present, ground radio to vehicle chassis.

All colors may not be present on all leads due to manufacturer's specifications.



NOTES

99-9106 INSTRUCTIONS



1-800-221-0932



www.metraonline.com

REV. 10/09/08 © COPYRIGHT 2001-2008 METRA ELECTRONICS CORPORATION INST99-9106