

SPECTRE

Intake Installation Instructions

P/N 901127(red filter)

Year/Model

1966-67 Chevelle

Parts List

1 - Heat Shield- Driver's Side
1 - Bulb Seal- 20"
1 - Bulb Seal- 24"
1 - Intake Tube
1 - Low Profile Air Box

1 - Air Filter
1 - 4" 75° Flex Boot
1 - 4" Coupler
1 - Velocity Stack
4 - 4" Hose Clamps

1 - Air Cleaner Nut
1 - Sheet Metal screw
2 - Bolts
5 - Washers
2 - Lock Nuts

THIS IS A CUSTOM KIT AND THE TUBE MAY NEED TO BE CUT TO FIT YOUR VEHICLE ENGINE COMBINATION.

Step 1 - Install the airbox on the carburetor with the low profile wing nut.

Step 2 - Install coupler (with clamps), on the end of the airbox inlet.

Step 3 - Place the velocity stack adapter in the heatshield and install the flex coupler secondly making sure the flex boot is pushed completely against the heat shield. Once the adapter and flex boot are tight against the heatshield, fully tighten clamp. Install bulb seal around edge of the shield.

Step 4 - Remove any components from the corner of engine bay and install heatshield using existing hardware (Most kits utilize factory body hardware).

Step 5 - Test fit THE SHORT LEG tube LENGTH in the airbox coupler. Trim tube to desired dimension. Now determine THE LONG LEG tube length but keep in mind that the tube needs to go into coupler an inch AND TRIM TUBE TO DESIRED DIMENSION.

Step 6 - Place the tube in the flex boot and install into the coupler on the airbox secondly. Once everything is in place and lined up, fully tighten all clamps.

If you have any difficulties or questions regarding the installation of this intake system, contact the Spectre Performance Technical Department by email - Tech@spectreperformance.com or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.