

# SPECTRE

## Intake Installation Instructions

P/N 902282(red filter) - P/N 902282B (blue filter)  
P/N 902282K (black filter) - P/N 902282W (white filter)

Year/Model

**1968-74 Nova**

Parts List

1 - Heat Shield- Driver's Side	1 - Bulb Seal- 21"	2 - Velocity Stacks
1 - Bulb Seal- 6"	1 - DTM Plenum	6 - Hose Clamps
1 - Bulb Seal- 20"	1 - Intake Tube	1 - Sheet Metal Screw
2 - Bulb Seal- 26"	2 - Air Filters	4 - Bolts
1 - Heat Shield- Pass Side	2 - 4" 45° Flex Couplers	10 - Washers
1 - Bulb Seal- 5"	1 - 4" Coupler	4 - Lock Nuts

THIS IS A CUSTOM KIT AND THE TUBE MAY NEED TO BE CUT TO FIT YOUR VEHICLE ENGINE COMBINATION.

Step 1 - Install the DTM Plenum on the carburetor or TBI throttle body (5 1/8" opening) and secure it with the low profile air cleaner nut.

Step 2 - Install the 2" long coupler with clamps, on the inlet of the DTM Plenum.

Step 3 - Place the velocity stack adapters/funnels in the heat shields. Install the flex couplers making sure they are pushed completely against the heat shields. Once the adapter and the flex boot are tight against the heat shield, fully tighten the clamps. Install the bulb seal around edges of the shields.

Step 4 - Remove any components from the corners of engine bay and install the heat shields using the existing hardware, most kits utilize the factory body hardware.

Step 5 - Test fit THE SHORT LEG tube LENGTH in the DTM Plenum. Make sure there's clearance between the radiator/fan and tube WHILE CENTERING THE TUBE INTO THE COUPLER. Trim tube to desired dimension and then install tube to the DTM Plenum. Now determine THE LONG LEG tube length but keep in mind that the tube needs to go into coupler an inch AND TRIM TUBE TO DESIRED DIMENSION.

Step 6 - Install the intake "Y" tube in the flex boots and then install it into the coupler on the plenum. Check alignment of tube and fully tighten all clamps.

Step 7 - Install the air filters onto the velocity stack adapter with the supplied clamps and fully tighten.

If you have any difficulties or questions regarding the installation of this intake system, contact the Spectre Performance Technical Department by email - [Tech@spectreperformance.com](mailto:Tech@spectreperformance.com) or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

