

INSTALLATION MANUAL

13627

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Weight Carrying Capacity

Gross trailer weight (GTW)	5,000 lbs.
Tongue weight (TW)	500 lbs.

Weight Distribution Capacity

Weight distribution (WD)	5,500 lbs.
WD tongue weight (WDTW)	550 lbs.

Parts List

Item	Qty	Description
1	4	Hex bolt, M14-1.5 x 35mm
2	4	Conical-toothed washer, 9/16"

Tools Required

Ratchet	Torque wrench
Socket, 22mm	Socket, 10mm
Socket extension	Small screwdriver
Pliers	Tape measure

* For a tools reference guide visit curtmfg.com/trailer-hitch-installation

⚠ WARNING

Never exceed the vehicle manufacturer's recommended towing capacity.

Product Photo



NOTICE

Visit www.curtmfg.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

This installation requires:

- Temporarily remove bumper fascia support
- Remove hitch panel

Periodic inspection of the trailer hitch should be performed to ensure all mounting hardware remains tight and structural components are secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

SAFETY INSTRUCTIONS

Safety glasses should be worn at all times while installing this product.




Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtgroup.com/surveys

ASSEMBLY



Parts List

Item	Qty	Description
1	4	Hex bolt, M14-1.5 x 35mm
2	4	Conical-toothed washer, 9/16"



Step 1

Remove the ten (10) push pin fasteners with a flathead screw driver holding the bumper fascia to the bumper fascia support and the "hitch door" to both. Remove the two (2) clips with a straight screw driver fastening the rearward edge of the hitch door. Return the hitch door, clips and four (4) push pins to the vehicle owner.




Step 2

Remove the two (2) screws securing the bumper fascia support to the frame rails with a 10mm socket. Using pliers, twist the two (2) plastic plug clips while gently pulling downward to remove them. Remove the bumper fascia support and set it aside for later reinstallation.





Step 3

Remove the two (2) adhesive patches on the outer sides of the frame rails to gain access to the 14mm weldnuts. Using a 10mm socket, remove the two (2) nuts and two (2) bolts from the support bracket on the driver side.



Step 4

Before installing the hitch, use a tape measure to measure the very end of the side plates. The measurement of outside to outside should be no less than 44-5/8" but no more than 45". If it falls outside of these measurements, the plates will need to be adjusted into that range to ease installation.



Step 5

Gently raise and slide the hitch into position with the main body tube resting in the bumper fascia area. Be careful not to damage any electrical components, wiring or the bumper cover.



Step 6

Loosely secure the hitch with the supplied 14mm hex bolts (#1) and 9/16" conical-toothed washers (#2).



Step 7

Torque all 14mm fasteners to 136 lb-ft.



Step 8

Reinstall the support bracket with the hardware removed in step 3.

Reinstall the bumper fascia support back into position and reinstall the six (6) push pins attaching the bumper fascia to the bumper fascia support.



Final Installed Image



TOWING BASICS & SAFETY INFORMATION

For information on safely towing your trailer, visit curtmfg.com/understanding-towing.