



# INSTALLATION MANUAL

# DRAWER TRUCK TOOL BOX

## Level of Difficulty

Easy

## Parts List

1	Drawer truck tool box
2	Key
4	Hex bolt, 1/4" x 1-1/4"
8	Flat washer, 1/4"
4	Nylock nut, 1/4"

## Tools Required

Drill	Drill bit set
Ratchet	Socket set
Tape measure	--

## Torque Specifications\*

Metric	M6 bolt	3 ft-lbs.
	M8 bolt	7 ft-lbs.
	M10 bolt	16 ft-lbs.
	M12 bolt	28 ft-lbs.
SAE	1/4" bolt	3 ft-lbs.
	5/16" bolt	7 ft-lbs.
	3/8" bolt	16 ft-lbs.
	7/16" bolt	20 ft-lbs.
	1/2" bolt	28 ft-lbs.

\* Above specifications are general guidelines. If purchasing hardware use the torque specifications provided with that hardware.

## Maintenance

For polished, gloss and other smooth finishes, polish may be used to clear small scratches and scuffs on the finish.

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

## ⚠ DANGER

Danger of explosion. Do not use this product for storing or transporting flammables, explosives, hazardous materials or hazardous waste, such as containers of gasoline, solvents, gun powder, dynamite, propane tanks, acetylene tanks and cutting torches.

## ⚠ WARNING

Never exceed the vehicle manufacturer's recommended capacity. Do not interfere with factory-installed safety equipment.

## Representative Product Photos (your specific box may vary in style, size or finish)



## NOTICE

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

To help prevent damage to the product or vehicle, refer to the torque specifications when securing hardware during the installation process.

Do not use this product for purposes other than those for which they were designed. Never modify this product.

Consult your dealer if you have any questions regarding the installation, operation, use and limits of this product.

Treat or seal all fasteners and exposed metal in any holes drilled in vehicle to prevent corrosion.

## Product Registration and Warranty

CURT Group stands behind our products with industry-leading warranties. Provide feedback and help us to improve our products by registering your purchase at: [warranty.curtgroup.com/surveys](http://warranty.curtgroup.com/surveys)

## Step 1

### **⚠ WARNING**

Before drilling into your truck bed, check under your vehicle to ensure the drill location does not puncture, cut or obstruct any brake or fuel fluid lines, electrical wires, fuel tanks, etc. Precaution must be taken that all fasteners near the fuel tank do not create the possibility of fuel tank puncture or other damage during a collision.

Remove the bottom two drawers from the tool box and place the tool box on the mounting surface. Mark the mounting surface using the guide holes on the inside of the tool box.

Drill 1/4" holes. Align the holes in the tool box with the drill holes in the mounting surface.

Insert one 1/4" bolt and flat washer on the inside of the tool box and secure with one flat washer and nylock nut on the underside of the mounting surface. Do this for each mounting hole. Tighten all hardware.

Re-install the bottom two drawer slides.

## Step 2

### **⚠ CAUTION**

Ensure all knobs, bolts, screws, straps and locks are firmly secured before every trip. Periodically re-tighten and inspect all components for signs of wear, corrosion and fatigue.

With the drawer tool box installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

To protect your investment, see the 'Maintenance' section on page 1.

Congratulations on the installation of your new UWS drawer truck tool box.

